

1. Tried the normal procedure of bootloading ( Burn Bootloader option in Arduino IDE), it failed. Checking on avrdude gave this error,

```
Error while burning bootloader.

Programmer Type : STK500
Description      : Atmel STK500 Version 1.x firmware
Hardware Version: 2
Firmware Version: 1.18
Topcard         : Unknown
Vtarget        : 0.0 V
Varef          : 0.0 V
Oscillator      : Off
SCK period     : 0.1 us

avrdude.exe: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.03s

avrdude.exe: Device signature = 0x000000 (retrying)

Reading | ##### | 100% 0.02s

avrdude.exe: Device signature = 0x000000 (retrying)

Error while burning bootloader.
Reading | ##### | 100% 0.02s

avrdude.exe: Device signature = 0x7fffff
avrdude.exe: Expected signature for ATmega328PB is 1E 95 16
                Double check chip, or use -F to override this check.

avrdude.exe done. Thank you.
```

```
C:\Users\hp>avrdude -c avrisp -p m328pb -b 19200 -P COM8 -n

avrdude: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.07s

avrdude: Device signature = 0x000000 (retrying)

Reading | ##### | 100% 0.08s

avrdude: Device signature = 0x7f7f00
avrdude: Expected signature for ATmega328PB is 1E 95 16
                Double check chip, or use -F to override this check.

avrdude done. Thank you.

C:\Users\hp>
```

2. Downloaded latest release of Optiboot bootloader , <https://github.com/Optiboot/optiboot>  
Also, getting an option of only ATmega328p in the processors for Optiboot on 32-pin CPUs.  
Changed the signature of ATmega328pb to ATmega328p (read somewhere that treating 328PB like 328P helps)  
Getting this error,

```
Error while burning bootloader.
Programmer type : STK500
Description      : Atmel STK500 Version 1.x firmware
Hardware Version: 2
Firmware Version: 1.18
Topcard         : Unknown
Vtarget        : 0.0 V
Varef          : 0.0 V
Oscillator      : Off
SCK period     : 0.1 us

avrdude: AVR device initialized and ready to accept instructions

Reading | ##### | 100% 0.02s

avrdude: Device signature = 0x000000 (retrying)

Reading | ##### | 100% 0.02s


avrdude: Device signature = 0x000000 (retrying)

Error while burning bootloader.
Reading | ##### | 100% 0.02s

avrdude: Device signature = 0x000000
avrdude: Yikes! Invalid device signature.
        Double check connections and try again, or use -F to override
        this check.
```

3. Tried to flash the bootloader directly with AVRdude,

```
avrdude -c avrisp2 -B 10 -p atmega328p -e -U flash:w:optiboot_m328p.hex:i -U lfuse:w:0xFF:m -U hfuse:w:0xD6:m -U efuse:w:0xFD:m -U lock:w:0xCF:m
Getting this error,
```



```
Command Prompt
avrdude: AVR device initialized and ready to accept instructions
Reading | ##### | 100% 0.08s
avrdude: Device signature = 0x000000 (retrying)
Reading | ##### | 100% 0.06s
avrdude: Device signature = 0x000000 (retrying)
Reading | ##### | 100% 0.08s
avrdude: Device signature = 0x000000
avrdude: Yikes! Invalid device signature.
        Double check connections and try again, or use -F to override
        this check.

avrdude done. Thank you.

C:\Users\hp>avrdude -c avrisp2 -B 10 -p atmega328pb -e -U flash:w:optiboot_m328pb.hex:i -U lfuse:w:0xFF:m -U hfuse:w:0xD6
:m -U efuse:w:0xFD:m -U lock:w:0xCF:m
avrdude: ser_open(): can't open device "\\.\com1": The system cannot find the file specified.

avrdude done. Thank you.


C:\Users\hp>
```

avrdude.exe: Device signature = 0x1e9516 (probably m328pb)

Thought of adding the COM port and baud rate after this error, so tried this,

```
avrdude -c avrisp -B 10 -p atmega328pb -P COM8 -b 19200 -e -U  
flash:w:optiboot_m328pb.hex:i -U lfuse:w:0xFF:m -U hfuse:w:0xD6:m -U  
efuse:w:0xFD:m -U lock:w:0xCF:m
```

Got this as error,



```
Getting this error  
Command Prompt  
avrdude: stk500_getsync() attempt 10 of 10: not in sync: resp=0xe0  
avrdude done. Thank you.  
  
C:\Users\hp>avrdude -c avrisp -B 10 -p atmega328pb -e -U flash:w:optiboot_m328pb.hex:i -U lfuse:w:0xFF:m -U hfuse:w:0xD6  
:m -U efuse:w:0xFD:m -U lock:w:0xCF:m -P COM8 -b 19200  
avrdude: AVR device initialized and ready to accept instructions  
Reading | ##### | 100% 0.08s  
avrdude: Device signature = 0x000000 (retrying)  
Reading | ##### | 100% 0.08s  
avrdude: Device signature = 0x000000 (retrying)  
Reading | ##### | 100% 0.06s  
avrdude: Device signature = 0x000000  
avrdude: Yikes! Invalid device signature.  
Double check connections and try again, or use -F to override  
this check.  
  
avrdude done. Thank you.  
C:\Users\hp>
```

#### 4. Uploading optiLoader.ino onto the chip

<https://github.com/WestfW/OptiLoader>

Getting some error like this, will upload the exact error too.

Using library OptiLoader-master in folder:

C:\Users\hp\Documents\Arduino\libraries\OptiLoader-master (legacy)

exit status 1

'SPCR' was not declared in this scope