



Connector Part Information		<ul style="list-style-type: none"> • 1.0L VIN 6 Manual Transmission • 26 Pin Green Connector C1 	
Pin	Wire Color	Circuit No.	Function
C1 - 1	BLK/GRN	—	PCM Ground
C1 - 2	WHT/BLU	—	Ignition Positive Voltage
C1 - 3	RED/WHT	—	EVAP Canister Vent Solenoid Control
C1 - 4	PNK	—	HO2S 2 Heater Control
C1 - 5	RED/BLK	—	Exhaust Gas Recirculation (EGR) Bypass Valve Control
C1 - 6	GRN	—	Exhaust Gas Recirculation (EGR) Solenoid Vacuum Valve Control
C1 - 7	RED/GRN	—	EVAP Canister Purge Valve Control
C1 - 8	—	—	Not Used
C1 - 9	—	—	Not Used
C1 - 10	ORN	—	Ignition Trigger Signal
C1 - 11	GRY/YEL	—	Idle Speed Control (ISC) Motor Control
C1 - 12	YEL/BLK	—	Fuel Injector Control
C1 - 13	BLK/BLU	—	PCM Ground
C1 - 14	WHT	—	Memory Power Input
C1 - 15	WHT/BLU	—	Ignition Positive Voltage
C1 - 16	GRY/BLK	—	Idle Speed Control (ISC) Motor Relay Control
C1 - 17	PPL/YEL	—	Malfunction Indicator Lamp (MIL) Control
C1 - 18	PPL/RED	—	Upshift Indicator Lamp Control
C1 - 19	RED/BLU	—	EVAP Tank Pressure Control Solenoid Valve Control
C1 - 20	BLU	—	Engine Cooling Fan Relay Control
C1 - 21	PNK/WHT	—	Fuel Pump Relay Control
C1 - 22	BLU/BLK	—	Main Relay Control
C1 - 23	BRN	—	Not Used
C1 - 24	GRY/RED	—	Idle Speed Control (ISC) Motor Control
C1 - 25	YEL/RED	—	Early Fuel Evaporative (EFE) Heater Relay Control
C1 - 26	BLK/RED	—	PCM Ground